



01	77A100420	Barrel Nut Assembly
02	44-915410-2075	Desoldering Tip, 44-915410-2075 (1.0mm)
	44-915412-2075	Desoldering Tip, 44-915412-2075 (1.2mm)
	44-915415-2075	Desoldering Tip, 44-915415-2075 (1.5mm)
3-7	79ADIA80	Desolder Heater Assembly
04	27-020010	Radiator Spacer
05	27-020008	Bakelite Heater Holder
06	52-010013	Vacuum Seal
07	66A213059	Heater PCB Assembly
08	38-011003	Insulation Partition
09	26-020206	Push Button
10	26-100205A	ESD Desoldering Plastic Handle
11	26-0114191	Plastic Set Screw M6*6
12	34-870414	ESD 7-wire Silicone Rubber Cable
13	60-130711	7-pin Cable Connector (Female)
14	29-010016	Cooling strip
15	75-160110	Glass Solder Collector
16	76-1411030	Cotton Filament 10pcs/ Polybag
17	42-040024	Fume Reducer
18	52-010010	Vacuum Seal A
19	45-106016	Vacuum Sealing Stopper
20	50-101033	Tension Spring
21	26-020207	Lock
22	37-061030	Silicone Rubber Tube
23	50-207708	Clip
24	26-040040	Filter Cap "A"
25	78-151500	Filter for DIA80
26	52-020011	Seal O-Ring
27	26-040041	Filter Cap "B"
28	26A04004AB	Filter Cap Assembly
	DIA80T	Desoldering Iron for LF8000, LF6000
	50-100730	Probe 0.7 (Clean the Desoldering Tip)
	91-040004	Cleaning Brush for the glass collector